



www.clearsonic.com (330) 650-1420

ADDITIONAL PANEL(S) INSTALLATION INSTRUCTIONS

What you will need: Rubber hammer, rubbing alcohol, and a lint free cloth. Hinge replacement is much easier if you have an assistant and work on a carpeted surface. We do not recommend attaching more than seven panels in one system.

How you do it:

1. First, fold the panel system together and carefully lay the system over onto the long edges with the edge of the panel you will be connecting to facing up. Have your assistant hold the panels (or lean them against a wall if you have to).
2. Wipe down the panel edge with rubbing alcohol and cloth to lubricate the edge of the panel you will be attaching to.
3. Make sure that the tooth in the hinge channel is configured so that it will snap into the groove on the long edge of your ClearSonic Panel sections. Rotate the whole hinge if not.
4. **Line up the new panel(s) so that all panels are flush at the bottom** so that the system will be level once set up. Configure the hinge so it folds into an upside-down "U".
5. Attach the hinge to the outside edge of your original panel system and seat it so that the channel tooth snaps into the groove. **Do not slide hinge on to panel!**
6. After making sure the base of the panels line up (*very important, use your rubber hammer to tap from the bottom to help you line them up if needed*), start the hinge onto the mating panel with your hands. After starting the hinge, **go back and look to make sure the base is still lined up. If not, tap the bottom of the panels till they line up.**
7. Seat the hinge by pushing down with your hands and making sure the tooth snaps into the groove the whole length of the panel. If needed, tap it on with your rubber hammer. Eye it from one end to make sure it is seated the entire length. Set it up and you're done!

Please feel free to call us with any questions that you might have.

Thank you for using ClearSonic products!