



www.clearsonic.com 800.888.6360

### **Base Channel Installation**

1. Spread panels open accordion-style with the bottom up.
2. Wipe base with rubbing alcohol to lubricate area.
3. While base is still wet, press base channel onto panels.
4. Continue steps until all panels are complete.

Thank you for using ClearSonic products. Please contact us should you have any questions or concerns about assembly or operation.  
800-888-6360 \* info@clearsonic.com