

ClearSonic Hinge Replacement/Panel Addition



1. Lubricate panel with rubbing alcohol



2. Line up hinge with panels



3. Snap hinge into groove on *one* panel by pressing straight down



4. Continue seating hinge into groove



5. Bend hinge over onto adjoining panel and snap into groove. Attach completely to entire length of adjoining panel.



Your panels are now attached. Please call if you have any questions.